



ASSEMBLY INSTRUCTIONS

ASSEMBLING

Shipping KD and assembled – Our garage cabinets can be shipped two different ways. If you are a handy person and want to save on freight, we suggest shipping the cabinets in a knockdown form, which you assemble when it arrives. Otherwise, pre-assembly is always available.

INSTALLATION GUIDE AND TIPS

Installing our garage cabinets is not difficult if you adhere to a few installation guidelines.

1. First, make sure that all of your cabinet boxes are built but no doors, drawers, or shelves are attached.
2. Measure out the wall where you will be installing the cabinets and make sure that there is not a conflict with light switches, electric plugs, garage door openers, etc. Relocate anything that conflicts or rout out the back of the corresponding cabinets so you can gain access from inside the cabinet.
3. Using a stud finder, locate all wall studs. Generally studs are supposed to be 16" on center but do not rely on this. Rely on the stud finder.
4. Use 3" course thread screws with 1/4" fender washers to attach cabinets to the studs. The fender washers allow for more holding power and keep the screws from sucking through the back.
5. A level is very important when installing and getting a professional look. Garage floors are not flat and should not be trusted.
6. When installing cabinets on a side wall of a garage, start at the back and work toward the front. The floor's highest point is generally in the back of the garage.
7. Use drywall shims or wedges if the walls are extremely out of square to get the perfect look.
8. Screw a few cabinet boxes together with 1-1/4" screws or connecting screws before attaching to the wall. This will ensure that the fronts of the cabinet boxes are straight and flush.
9. Smaller cabinets should have a minimum of four screws secured to the studs. Larger cabinets should have a minimum of six screws secured to the studs.
10. Use all three adjustments on the blum hinges in order to get the perfect fit.